

CAULKING AND TOUCH UP PROCESS OF URESTONE

STEP 1 APPLY COLORED CAULK TO INTERLOCKS AND SCREW HEADS.

STEP 2 SPRAY SOAPY WATER SOLUTION

STEP 3 SMOOTH OUT CAULK

STEP 4 USE A BRUSH TO ADD TEXTURE TO CAULK

STEP 5 USE TOUCH UP PAINT IF CAULK DOES NOT MATCH EXACTLY

